

#9991 Corner Shop Kit

Step-by-step assembly instructions

Copyright miniatures.com 2013, 2024

PARTS LIST:

Corner Wall With Door
Left Wall With Bay Window
Right Wall With Bay Window
Left Back Wall
Right Back Wall
Base
Grooved Trim for top (5)
Plexi Glass for top
Corner Top Facade
Side Top Facade (2)
Oval Trim
Large Plexi for Bay Window (2)
Narrow Plexi for Bay Window (4)

SUPPLIES NEEDED:

Masking tape
White glue (such as #1249 Weldbond)
Damp clean cloth
Exterior and interior finishes



GENERAL INSTRUCTIONS

- Identify and inspect all parts using the Parts List and Parts Diagram.
- Read the directions completely before beginning the project.
- If possible, have a dedicated work area so that you are not unpacking, repacking, and moving the project from place to place.
- Choose a work surface that is level, clean, dry, and protected from glue spills.
- Do a dry fit, using masking tape to hold parts in place, to make sure everything fits together correctly before assembling permanently.

 **WARNING:**
CHOKING HAZARD – Small parts
Not for children under 3 yrs.
Adult supervision required.

Assembly Instructions

1. Follow the assembly exploded design looking at each piece from the outside. Use the base as a guide to place shop on during assembly but do not glue in place at this time.
2. Glue the right end of **Left Back Wall** (narrow trim piece at top to the inside and wider trim at bottom on outside) into the groove on the back of the left side of **Left Wall With Bay Window**. Be sure bottom and top edges of walls are flush. Secure with pieces of masking tape. Allow to dry.
3. Glue the left side of **Left Back Wall** into groove and angle trim on right side of **Right Back Wall** (narrow trim at top on the inside with wider trim at bottom and angle corner on the outside). Be sure bottom and top edges of walls are flush. Secure with masking tape. Allow to dry.
4. Glue the left side of **Right Back Wall** into groove on the back of right side of **Right Wall With Bay Window**. Flush at top and bottom. Secure with masking tape. Allow to dry.
5. With this part of assembly setting loose on the base, be sure the corners are square.
6. Glue the right side of **Left Wall With Bay Window** into the groove on the left side of **Corner Wall With Door** and

Tips:

- Remove paper from plexiglass before installing in the front windows.
- Remember, it is easier to work on the individual walls on your work table before assembling the shop.
- Suggested Finishing Techniques **BEFORE** Construction:
 - Stain or Paint walls, facade and trims before assembling the store.
 - Apply any outside finish, such as: Brick or Clapboard.
 - Decide how you are going to finish the inside of the store; the walls, electrify the store, hard wire or tape wire?
 - Fit and match wallpaper, wainscoting, paneling, etc. to inside of walls and apply.
 - The plexiglass included for the front windows can be used clear or made into "stained glass" windows. (See "stained glass" windows in "Everything You Wanted To Know About Dollhouses But Didn't Know Who To Ask" instruction book.) Glue the plexiglass into the windows. Be careful to only put glue on the edges. "Stained glass" windows should be finished before gluing in place.
 - Fit any window treatments and secure in place.
 - Glue hardware on door.
 - If **Framed Plexiglass Top** is not assembled, fit the four pieces of grooved trim around large piece of plexiglass and glue at joints. Do not get glue on visible area of plexiglass. Secure with masking tape and allow to dry.

glue the left side of **Right Wall With Bay Window** into the groove on the right side of **Corner Wall With Door**. Secure with masking tape. Allow to dry.

7. Set **Framed Plexi-Glass Top** on top of assembly to help keep it square.
8. Fit **Side Top Facade** on top of **Walls With Bay Windows** and **Corner Top Facade** on top of **Corner Wall With Door** behind the dentil trim. Make sure the angle edges of **Corner Top Facade** are on the back and fit against the ends of the **Side Top Facade** pieces. Glue in place. The **Framed Plexi-Glass Top** will fit behind the facades on top of the walls flush with the outside edge and inside the angle corner trim.

9. After the assembly has dried completely and before gluing it to the base, draw around the inside of the assembly to make a pattern for the floor covering on the base. Remove the assembly from the base. With a piece of tracing paper, trace the drawing, cut around the traced drawing and use the cut out piece for a pattern. Using the pattern, cut the wood flooring, carpet, tile, etc. Apply within design on base.
10. Glue assembly to base around floor covering. Now baseboard can be applied to the walls if you so desire.

Parts Layout Diagram

PARTS KEY:

- A - Corner Wall With Door
- B - Left Wall With Bay Window
- C - Right Wall With Bay Window
- D - Left Back Wall
- E - Right Back Wall
- F - Base
- G - Framed Plexi Glass Top
- H - Corner Top Facade
- I - Side Top Facade
- J - Oval Trim
- K - Large Plexi for Bay Window
- L - Narrow Plexi for Bay Window

